

plus One[®]

rose arouser




instruction manual



product overview

1) power button

Press and hold the power button for 3 seconds to turn on. Press firmly to cycle through the 10 settings. Press and hold for 3 seconds to power off.




2) charging port

Attach the magnetic charging head to the charging contact.


how to charge



1. The charging contact is a small metal circle located on the bottom of the device.



2. Line up the magnetic charging head with the charging contact.



3. The cable will magnetically attach itself into place. The power button LED light will pulsate slowly to indicate charging.

special instructions:

Do not turn on while charging and/or cleaning. (While charging the light will flash; the light will turn solid when fully charged) Low battery alert: Light will flash rapidly when battery is running low. Use only with 5-volt USB wall adapter (standard mobile phone charger). Allow 120 minutes for a full charge. Use water based lubricant only.

cleaning:

Clean thoroughly with mild soap and warm water, before and after each use.

storage:

Store in a cool dry place separately from other sex toys; sex toys of different material can damage each other if left in contact.

quality:

This product is manufactured using body-safe silicone that is harmless to the human body; free from phthalates, BPA and latex.

warnings:


Discontinue use if there is any discomfort for you or your partner. Do not expose device to water while charging.

ways to use




warming up?

Use the rose arouser to caress your or your partners' breasts, focusing on the nipples, to slowly increase arousal



explore the sensations

Press the pulsing head directly on, or near, the clitoris for heightened external stimulation. Explore by brushing the arouser's vibrating petals directly against, or near, your vulva.



switch things up

Reverse the rose arouser on your partner to get them in the mood. Explore each of the 10 pulsing pleasure settings for teasing and eventually, reaching euphoric climax.

The battery shall be disposed in accordance with the local laws and regulations. If possible please recycle it. Users shall not take out or replace the battery by themselves; doing so may damage the product.

two year limited warranty:

Your new plusOne® products carry a warranty against manufacturing defects for two years from the date of original purchase. plusOne® will, at our option and upon submission of a valid proof of purchase within the warranty period, repair or replace the product free of charge.

For assistance or for issues related to performance, damages, warranty, regular maintenance or customer feedback please contact plusOne® toll free at (800) 514-2546, Monday – Friday from 8:30 am until 5:30pm EST or email us at info@myplusOne.com