


vibrating ring



instruction manual

product overview:



special instructions:

Do not turn on while charging and/or cleaning. While charging the light will flash, the light will turn solid when fully charged. Use only with 5-volt USB wall adapter (standard mobile phone charger). Use water based lubricant only.

how to wear:

There are many uses and many ways to wear your new vibrating ring. Put on with care, stretching the ring first and slowly placing over an erect or semi-erect penis. If there is any discomfort please remove.

cleaning:

Be sure to clean thoroughly before & after each use. Clean using a mild soap and warm water.

storage:


Store in a cool dry place separately from other sex toys; sex toys of different material can damage each other if left in contact.

quality:

This product is manufactured using body-safe silicone that is harmless to the human body; free from phthalates, BPA and latex.

warnings:

Discontinue use if there is any discomfort for you or your partner. The ring should be comfortably snug. Do not wear longer than 30 minutes. This is for external use only.



The battery shall be disposed in accordance with the local laws and regulations. If possible please recycle it. Users shall not take out or replace the battery by themselves; doing so may amage the product.

two year limited warranty:

Your new plusOne[™] products carry a warranty against manufacturing defects for two years from the date of original purchase. plusOne[™] will, at our option and upon submission of a valid proof of purchase within the warranty period, repair or replace the product free of charge. For assistance or for issues related to performance, damages, warranty, regular maintenance or customer feedback please contact plusOne[™] toll free at (800) 514-2546, Monday – Friday from 8:30 am until 5:30pm EST or email us at info@myplusOne.com