


plus One[®]

vibrating wand




instruction manual


product overview




how to charge



1. The charging contact is a small metal circle located on the bottom of the device.



2. Line up the magnetic charging head with the contact.



3. The cable will magnetically attach itself into place. The power button LED light will pulsate slowly to indicate charging.

special instructions:

Do not turn on while charging and/or cleaning. While charging the light will flash, the light will turn solid when fully charged. **Low battery alert:** Light flashes rapidly when battery is running low. Allow at least 120 minutes for a full charge. Use only with 5-volt USB wall adapter (standard mobile phone charger). Use water based lubricant only.

cleaning:

Be sure to clean thoroughly before & after each use. Clean using a mild soap and warm water.

storage:

Store in a cool dry place separately from other sex toys; sex toys of different material can damage each other if left in contact.

quality:

This product is manufactured using body-safe silicone that is harmless to the human body; free from phthalates, BPA and latex.


warnings:

Discontinue use if there is any discomfort for you or your partner.


ways to use



If you'd like to feel some good vibrations throughout your body, place the wand on your labia. They'll conduct the vibrations throughout your vulva, giving you a more full-body experience.



If your clitoris craves something super-charged, this is the toy for you. Place the wand directly against, or near, your clitoris to experience its powerful vibrations at their full intensity.



"Massager" isn't just a euphemism: this wand feels fantastic on sore muscles and stubborn knots. If you're having trouble shaking off the stress of a long day, the wand can be exactly the foreplay you need to let go of your stress and get into the mood.

The battery shall be disposed in accordance with the local laws and regulations. If possible please recycle it. Users shall not take out or replace the battery by themselves; doing so may amage the product.

two year limited warranty:

Your new plusOne® products carry a warranty against manufacturing defects for two years from the date of original purchase. plusOne® will, at our option and upon submission of a valid proof of purchase within the warranty period, repair or replace the product free of charge.

For assistance or for issues related to performance, damages, warranty, regular maintenance or customer feedback please contact plusOne® toll free at (800) 514-2546, Monday – Friday from 8:30 am until 5:30pm EST or email us at info@myplusOne.com