

plus One[®]

luxe dual massager



instruction manual




product overview

1) power button

Press and hold the power button for 3 seconds to turn on. Press firmly to cycle through the 10 settings. Press and hold for 3 seconds to power off.

2) stroking button


Press the circle button to start, and toggle through the 5 stroking motions. The circle button light will illuminate. To turn stroking motions OFF, toggle to the end of the 5 settings.




3) charging port

Attach the magnetic charging head to the charging contact.


how to charge



1. The charging contact is a small metal circle located on the back of the device.



2. Line up the magnetic charging head with the charging contact.



3. The cable will magnetically attach itself into place. The power button LED light will pulsate slowly to indicate charging.

special instructions:

Do not turn on while charging and/or cleaning. (While charging the light will flash; the light will turn solid when fully charged) Low battery alert: Light will flash rapidly when battery is running low. Use only with 5-volt USB wall adapter (standard mobile phone charger). Allow 130 minutes for a full charge. Use water based lubricant only.

cleaning:

Clean thoroughly with mild soap and warm water, before and after each use.

storage:

Store in a cool, dry place separately from other sexual wellness devices; sexual wellness devices of different material can damage each other if left in contact.

quality:

This product is manufactured using body-safe silicone that is harmless to the human body; free from phthalates, BPA and latex.


warnings:

Discontinue use if there is any discomfort for you or your partner. Do not expose device to water while charging.


ways to use



Insert the luxe dual massager's longer internal arm into your vagina and position the shorter external arm against your clitoris for intense dual pleasure (don't forget the lube!). Press the power button to cycle through the 10 vibration settings.



Slide the larger internal arm into your or your partner's vagina, and tilt the luxe dual massager's handle down to apply direct pressure to the g-spot. Press the circle button to activate the stroking massaging bead and cycle through the 5 motions to experience mind-blowing g-spot stimulation.



Enjoy your fully waterproof luxe dual vibrating massager in the bath or shower for the ultimate way to relax and unwind. Independently control the 10 vibration settings and 5 stroking motions for 65 unique stimulation combinations.

The battery shall be disposed in accordance with the local laws and regulations. If possible please recycle it. Users shall not take out or replace the battery by themselves; doing so may damage the product.

two year limited warranty:

Your new plusOne® products carry a warranty against manufacturing defects for two years from the date of original purchase. plusOne® will, at our option and upon submission of a valid proof of purchase within the warranty period, repair or replace the product free of charge.

For assistance or for issues related to performance, damages, warranty, regular maintenance or customer feedback please contact plusOne® toll free at (800) 514-2546, Monday – Friday from 8:30 am until 5:30pm EST or email us at info@myplusOne.com